QUICK START GUIDE

HERO4 SILVER /MUSIC

Download the User Manual at
gopro.com/support

GoPro®
Be a *HERO.*

When using your GoPro camera as part of your active lifestyle, always be aware of your surroundings to avoid injury to yourself and others, and to prevent damage to your camera.

Before using your GoPro camera, please read carefully all the safety precautions in the Important Product + Safety Information Guide included with your camera.

/ Hello

Congratulations on your new HERO4 Silver camera. This Quick Start Guide will show you the basics of capturing life's most incredible moments with your GoPro.

To learn more, download the User Manual at **gopro.com/support**.

JOIN THE GOPRO MOVEMENT

facebook.com/GoPro

youtube.com/GoPro

twitter.com/GoPro

instagram.com/GoPro

/ Getting Started

STEP 1
Remove the camera from The Frame.

STEP 2
Remove the camera side door and insert a microSD card (sold separately).

*(Requires a Class 10 or UHS-1 card. For a list of the recommended SD cards, visit **gopro.com/support**.)*



STEP 3
Open the battery door and insert the battery.



STEP 4
Charge the battery using the included USB cable.



/ The Basics



POWERING CAMERA ON AND OFF

To Power On:
Press the **Power/Mode** button [ ].

To Power Off:
Press and hold the **Power/Mode** button [ ] for two seconds.

/ Touch Display

Frame your shots, play back footage and quickly adjust settings on the camera's touch display.

TOUCH SCREEN GESTURES

Swipe Left

Display camera modes.



Swipe Up from Bottom Edge

Open the settings menu for the current mode.



Swipe Up/Down

Move through settings lists.



Tap

Select an item or turn a setting on/off.



Swipe Left/Right

Display gallery images (**Playback** mode).



Double Tap

Change field of view (FOV) in preview mode.



/ Selecting Camera Modes

1. Swipe left on the touch display, and then tap the desired camera mode.

Camera Modes		Description
	Video	Video, Video + Photo, Video Looping
	Photo	Single, Night, Continuous
	Multi-Shot	Burst, Time Lapse, Night Lapse
	Playback	Play back videos and photos
	Setup	Adjust general camera settings

2. If necessary, select a different capture mode:
   a. Swipe up to open the settings menu.
   b. Tap Mode, and then tap the desired capture mode.
   c. Swipe down to close the settings menu.

/ Capturing Video and Photos

Select your camera mode, then press the **Shutter/Select** button [ ] to start/stop recording or take a photo.



QUIKCAPTURE

When the camera is off and QuikCapture is enabled, you can turn the camera on and immediately begin capturing video or Time Lapse photos just by pressing the **Shutter/Select** [ ] button. Press once for video, press and hold for two seconds for Time Lapse photos. Press again to stop recording and power off the camera. You can turn QuikCapture on/off in Setup mode.

HILIGHT TAG

Press the **Settings/Tag** button [ ] to tag key moments while recording video. HiLight Tags help you quickly find the highlights later for easy play back, editing and sharing.

/ Adjusting Camera Settings

1. On the touch display, swipe left to display the camera modes.
2. Tap the desired mode.
3. Swipe up to display the settings menu for that mode.
4. Swipe up or down to scroll through the options.
5. Tap to select your desired option.
6. When finished, swipe down to exit the settings menu.

To learn more about settings, download the User Manual at **gopro.com/support**.



/ Mounting Your Camera

REMOVABLE INSTRUMENT MOUNTS

These easy-to-remove, non-damaging adhesive mounts are safe for use on most instrument surfaces.



To Install



Step 1
Peel off the adhesive strip's backing.



Step 2
Place mount on **clean surface** and **press firmly for 10 seconds.**

Note: The mount's adhesive strip cannot be re-used after removal, so double check your mounting location before applying.

To Remove

Step 1
Do **NOT** pull tab upward. Doing so may damage the mounting surface.



Step 2
Lift mount **gently** while **slowly** pulling tab **parallel to surface.** Failure to hold mount may cause it to snap back at you.

WARNING: Do not use on highly fragile or irreplaceable items. Failure to follow instructions may cause damage or injury. Adhesive may occasionally leave non-damaging residue that can be easily removed with a soft cloth.

/ Mounting Your Camera

MIC STAND MOUNT

Mount your GoPro to standard U.S. 5/8"-27 mic stands. Includes an adapter for European 3/8"-16 mic stands.



SIDE MOUNTING



VERTICAL MOUNTING



/ Mounting Suggestions

Here are a few ways you can mount your GoPro to instruments and equipment.



/ Playing Back Videos and Photos

There are several ways to play back your videos and view your photos.

CAMERA
Play back content on the camera's touch display.

COMPUTER
Connect the camera to your computer with the included USB cable to transfer content for playback.

For help accessing your GoPro content, download the latest GoPro software at **gopro.com/getstarted**.

SMARTPHONE + TABLET
Use the GoPro App to play back content on your smartphone or tablet. For more info, see *GoPro App*.

TV
Connect your camera to your TV with a micro HDMI, composite or combo cable (sold separately).

/ Sharing Videos and Photos

There are a few ways to share your videos and photos.

COMPUTER
Connect the camera to your computer with the included USB cable to transfer content for sharing.

SMARTPHONE + TABLET
Use the GoPro App to share videos and photos by text, email or on your social networks. For more info, see *GoPro App*.

/ GoPro App

CONTROL. VIEW. SHARE.

The GoPro App lets you control your camera remotely using a smartphone or tablet. See what your camera sees with live preview. View photos and play back videos, then share your favorites via email, text, Facebook, Twitter and more.

TO CONNECT TO THE GOPRO APP

1. Download the GoPro App and open it on your smartphone or tablet.
2. When the app stops searching, tap Connect Your Camera.
3. Follow the app's on-screen instructions to connect your camera. The default password is *goprohero*.

To learn more about the GoPro App, visit **gopro.com/getstarted**.

Available on the App Store

GET IT ON Google play

Download from Windows Store

/ Help and Resources

DOWNLOAD THE USER MANUAL

To learn more about your HERO4 Silver camera, download the User Manual at **gopro.com/support**.

CAMERA SOFTWARE UPDATES

To get the latest features and best performance from your GoPro, make sure you're using the most current camera software. You can update your camera software via the GoPro App or GoPro software. For more info, visit **gopro.com/getstarted**.

TUTORIAL VIDEOS

Watch how-to tutorials and get pro tips + tricks on making the most of your GoPro products at **gopro.com/getstarted.**

CUSTOMER SUPPORT

Need help? Want more info? Find answers to commonly asked questions and contact Customer Support at **gopro.com/support**.

REGULATORY INFORMATION

To see the complete list of country certifications, refer to the Important Product + Safety Information Guide included with your camera.

CE | HDMI™